


# ASSEMBLY INSTRUCTION

# BOOTY BUILDER


# KICKBACK




# BEFORE ASSEMBLY


- **This must be read before you start assembling this unit.**
- **You must follow the assembly instructions exactly as outlined.**
- **Assemble this unit starting at the beginning and work to the end.**
- **The assembly instructions are set out so that you are only doing one section at a time, therefore you will finish one section and move on to the next.**
- **If something is missing when assembling this unit, you must notify us of the partnumber of the exact nut, bolt or part that is missing.**
- **To help you assemble this unit we have used line drawings.**
- **Check the line drawings for the exact positioning of the parts.**
- **The unit will need to be checked at least once a week for nuts and bolts that can work loose, upholstered pieces working loose and wear on pivot assemblies.**


## TOOLS NEEDED




**2x 19mm**




1  
  
M12x120  
x4

2  
  
M12  
x8

3  
  
M12  
x4



1




D30x88  
x4

2




M12x90  
x2

3




Rubber  
x2




Stack cable tensioning


1




2




3




4



5



6





## **PREVENTATIVE MAINTENANCE SCHEDULE**

To ensure the full safety of Booty Builder equipment for customers, the facility operator is required to periodically inspect the equipment in the gym as follows:

### **Monthly**

- Inspect and remove any objects caught under the machine.
- Check the tension of the cables.
- Lubricate the guide rods using 3-IN-ONE oil on a cloth.
- Check for any nuts/bolts that may be loose.
- Check for any upholstered pieces that may be loose.
- Check for wear on pivot assemblies.

### **Every 2 Months**

- Check the condition of bearings.
- Check the condition of the guide wheels.

In case of equipment failure, please report the fault to our service team by emailing [serwis@marbo-sport.pl](mailto:serwis@marbo-sport.pl) or calling [+48 41 274 23 80](tel:+48412742380) extension 864 and stop using the equipment until the problem is fixed